



Customer	FAHMY FURNITURE
Sample ID	PLASTER SAND COD.001 – comp567
Test	AGGREGATES CHARACTERIZATION
Sample (g)	300
Lab address	PF Lab Services – Simbario (VV) – ITALY


Chemical Analysis: A scanning electron microscopy (SEM) is used for the chemical analysis





Element Symbol	Element Name	Concentration	Error
O	Oxygen	57.0	1.9
Si	Silicon	16.9	2.4
Mg	Magnesium	20.4	2.5
C	Carbon	3.4	4.5
Al	Aluminium	2.2	8.1

3. spot



			(Fe)		
0 78,9	1 2 35 counts in 120 seconds	3 4 5	6 7	8 9	10 11
	Element	Symbol Elem	ent Name Co	oncentration	nError
,	O	Oxyg	en 65.	.3	0.8
	Si	Silico	on 18.	.5	0.9
	Mg	Magn	nesium 8.1		1.8
١	Al	Alum	inium 4.7	7	2.1
	Fe	Iron	3.4		4.4

Personal Factory s.p.a. P. IVA 03062550797 viale F. Ceniti 101 – 89822 Simbario tel/fax: +39.0963.74257


Via dell'Unione, 7 20123 Milano tel/fax: +39.02.8707.83.17

info@personalfactory.eu www.personalfactory.eu



2. spot






Element Symbol	Element Name	Concentration	Error
Ca	Calcium	48.6	1.2
O	Oxygen	45.8	2.0
С	Carbon	1.9	2.4
Si	Silicon	1.9	4.2
Mg	Magnesium	1.8	5.6

Particles size distribution

Sieves mesh mall S Steel I.S.O. 3310 (UNI EN 933-2) and electric sieve shaker with timer (UNI EN 932-5 ISO 3310-1) were used to lead the analysis.



Particles size analysis

Diameter Sieve	Passing %
[µm]	-
3000	98,00
1000	87,88
850	84,92
710	81,95
600	77,88
500	73,71

Personal Factory s.p.a. P. IVA 03062550797 viale F. Ceniti 101 – 89822 Simbario tel/fax: +39.0963.74257

Via dell'Unione, 7 20123 Milano tel/fax: +39.02.8707.83.17

<u>info@personalfactory.eu</u> www.personalfactory.eu



300	58,59
212	43,07
100	11,90
80	2,90
63	1,29

NOTE

Particles size analysis shows that the sand has a particles distribution between 3000 μ m and 100 μ m. The sample of sand does not have filler (powder with particles size below 80 μ m).

In order to use the PLASTER SAND COD.001 in Personal Factory products especially in ISOLCOLL products it is necessary to sieve the sand with a 800µm sieve. To improve the workability of the products can be added about 20% of filler RIMACAL 6090.


The sand can be also used in ISOLMIX, RESTAUROMIX (only for the products as RESTAUROMIX TX RASO 10/20/50), ISOLFUGA and ISOLVASCHE products.

The colour of the sand is dark, so it is not adequate to produce coloured mortars.

RESULTS OF THE TEST

Plaster Sand cod.001 was tested in the ISOLCOLL products

FORMULATION- ISOLCOLL A10	
SUPER	
CHEMICAL KIT	2.0%
GREY CEMENT	25.5%
PLASTER SAND	51.0%
RIMACAL 6090	21.5%



The results of the test show that the sand can be used in the ISOLCOLL Products. It has a good workability and a good wetting capability over 20 minute. The test confirms the property of the tile adhesive.

	DATE	PERSONAL FACTORY REFERENT
	28/04/2017	Ing. Maria Grazia Spagnolo